

CHG 102

Digi-Wave™ 2-bay charger

USER MANUAL



Thank you for purchasing this Williams Sound product. This unit will charge any two Digi-Wave™ DLTs or DLRs at a time - with the exception of the DLR 50.

1. Plug the provided AC power cord into the socket on the charger's rear panel, and then plug into an AC wall outlet.
2. Charge up to two DLT/DLRs at a time by setting the transceiver/receiver onto the 30-pin connector in the charging bays.
3. The red LED blinks on DLT/DLR while charging. When your DLT/DLR is fully charged the green LED will stay on continuously.

⚠ CAUTION!

DLT 100/300 internal battery pack.

To reduce the risk of fire or burns, do not attempt to open, disassemble, or service the battery pack. Do not crush, puncture, short contacts or dispose of in fire or water. Do not incinerate or expose to temperatures above 140F (60C). Replace only with battery pack designated for this product. Rechargeable Lithium-polymer battery (Li-Po). Recycle or dispose of properly.

⚠ CAUTION!

The lithium batteries used in the DLT provide great performance and long life. But, like all lithium batteries, they do have a limited number of charge/discharge cycles. Lithium batteries may experience swelling if used beyond their expected lifecycle (2 years). If you notice swelling of the battery, please discontinue use and have the battery replaced. We recommend battery replacement after 2 years of use. For more information about replacing the battery, please visit our website at: <http://www.williamssound.com/digiwave-battery-replacement>.

Specifications

Power input:	110—240V AC @ 50-60 Hz
Power output:	5 volts DC @ 1.2 amps
Cable length:	6' (1.8 meters)
Compatible with:	DLT 300, DLT 100 2.0, DLT 100, DLR 360, DLR 60 2.0, DLR 60. NOT compatible with DLR 50.
Warranty:	90 days