

Infrared & Digital Solutions for Judicial Markets



Williams Sound is a global designer and manufacturer of wireless listening technologies, meeting the communication needs of the judicial market for more than 35 years. Our wireless technology includes both installed and complete packaged systems for use in hearing assistance and/or simultaneous interpretation. Our infrared systems provide secure transmission, ensuring your peace of mind in the most critical communication applications. Many Williams Sound systems meet the 2010 Americans with Disabilities Act (ADA) requirements and all are covered by an industry leading, five-year warranty.

Applications:

- Hearing assistance
- Language interpretation (up to 14 channels simultaneously)
- Jury deliberation rooms
- Language access
- Judges chambers

Complete Packaged Infrared and Digital Systems

WIR SYS TX7518

This system features the NEW WIR TX75 infrared emitter/modulator—ensuring participants in your small to mid-size courtroom receive direct, clear communication of your message without sacrificing security. The sleek and stylish TX75 is designed with a wide transmission angle to maximize coverage area up to 4,000 square feet (transmitter with slave) in single-channel mode. A single CAT-5 cable carries both power and signal to slaves—truly a one-cable connection. Mounting bracket and international power supply are included.

System Includes:

- (1) WIR TX75 infrared emitter/modulator
- (1) WIR TX75S slave transmitter
- (5) WIR RX18 under-the-chin, two-channel receivers
- (1) CHG 518 drop-in charger



WIR SYS 91V

Featuring NEW SoundPlus® Two-channel Infrared System

This complete turnkey infrared solution combines value and functionality. The all-in-one WIR TX90 modulator/emitter eliminates the need for rack space, while providing up to 28,000 square feet of coverage for your most demanding installs. (Receiver options determine coverage.) Courtroom participants will appreciate the comfort of the NEW WIR RX15-2 headset receiver, and you'll enjoy this high quality system backed by our industry-leading, five-year warranty. This system meets the 2010 Americans with Disabilities Act (ADA) requirements for hearing assistance.



WIR SYS 3

This professional, turnkey infrared solution features a rack-mountable modulator and emitter that offers unsurpassed coverage – up to 28,000 square feet. (Receiver options determine coverage.) Featuring the popular WIR RX18 under-the-chin rechargeable receiver, this system offers ease of use and maintenance. Simply place the receiver in the charging bay over night – ready for use during the next day's proceedings. This system meets the 2010 Americans with Disabilities Act (ADA) requirements for hearing assistance.



Infrared Receiver Selections

WIR RX15-2

NEW headset-style, two-channel receiver provides comfort and style.



WIR RX18

Popular under-the-chin, two-channel, stereo receiver. Easy maintenance. Use with the 5-bay CHG 518 charger.



WIR RX22-4

High sensitivity receiver for courts that need up to four channels of audio transmission. Ideal for multiple-language, hearing assistance or audio description applications.



Digi•Wave™ Language Interpretation System (DWS INT 1)

This completely portable, wireless system is designed for language interpretation use in the 2.4 GHz band. Ideal for small-to medium-size courtrooms, presentation-style conferences and meetings. Designed to provide all functions necessary for simultaneous interpretation of up to 5 languages where a floor, or common, language is used. Up to 5 interpreters can hear the main speaker. An unlimited number of listeners can select and listen to any one of the interpreters. Order DLR 50 receivers for any number of listen-only audience members. (DLR 50s sold separately.) Order additional DLT 100s for simultaneous interpretation of up to 14 languages.



**Other pre-packaged systems are available. Or contact us to custom package a system that meets all of your courtroom needs. Emitters are also available in white.*